

Installation Guide

MCI PRV24K is designed to operate on the discharge side of the AFD when it is in <u>air scrubbing mode</u> within containment. When utilizing this configuration, clean, purified and ionized air is distributed evenly throughout the containment, maximizing the air exchanges while extending the effectiveness of the filters, thus, shortening the time required to clean the area.

